

CB36 BLOWER KIT

FOR MODELS 2350, 2827, and 2941

| PARTS LIST | | | |
|------------|----------|------------------------------|------|
| KEY | PART NO. | DESCRIPTION | QTY. |
| 1 | 891492 | ASSEMBLY, BLOWER (B36) | 1 |
| 2 | 25598B | BOX, PAINTED BLOWER MOUNTING | 1 |
| 3 | 83172 | #10 x 1/2 TEK SCREW | 8 |

INSTALLATION INSTRUCTIONS

- A. REMOVE PANEL BEFORE BLOWER INSTALLATION.
- B. ATTACH BLOWER MOUNTING BOX TO THE REAR OF THE UNIT USING (4) FOUR OF THE SUPPLIED #10 SCREWS.
- C. THEN MOUNT THE BLOWER ASSEMBLY TO THE MOUNTING BOX WITH THE (4) FOUR REMAINING #10 SCREWS.

